



APPLICATION CHART

Tire Size	Wheel Size	Ounces	# Pump Strokes
7.50	10	24 oz.	3
20.5X8.0	10	24 oz.	3
205/50	10	16 oz.	2
155/80	13	16 oz.	2
175/80	13	16 oz.	2
195/75	14	24 oz.	3
205/75	14	24 oz.	3
215/75	14	24 oz.	3
205/75	15	24 oz.	3
225/75	15	24 oz.	3
235/75	15	32 oz.	4
7.50	16	32 oz.	4
215/85	16	24 oz.	3
225/75	16	24 oz.	3
235/85	16	32 oz.	4
245/75	16	32 oz.	4
265/75	16	32 oz.	4
285/75	16	40 oz.	5
8.75	16.5	24 oz.	3
9.5	16.5	32 oz.	4
8	17.5	24 oz.	3
9	17.5	32 oz.	4
10	17.5	32 oz.	4
215/75	17.5	24 oz.	3
225/75	17.5	32 oz.	4
245/70	19.5	32 oz.	4
225/70	19.5	32 oz.	4
9.00	20	48 oz.	6

Tire Size	Wheel Size	Ounces	# Pump Strokes
10.00	20	40 oz.	5
11.00	20	48 oz.	6
12.00	20	48 oz.	6
1100	22	48 oz.	6
10	22.5	40 oz.	5
11	22.5	48 oz.	6
12	22.5	48 oz.	6
255/70	22.5	40 oz.	5
265/75	22.5	40 oz.	5
275/70	22.5	48 oz.	6
295/75	22.5	48 oz.	6
295/80	22.5	56 oz.	7
305/70	22.5	56 oz.	7
315/75	22.5	56 oz.	7
315/80	22.5	56 oz.	7
385/65	22.5	72 oz.	9
425/65	22.5	80 oz.	10
445/45	22.5	72 oz.	9
445/50	22.5	72 oz.	9
445/55	22.5	80 oz.	10
445/65	22.5	88 oz.	11
455/45	22.5	72 oz.	9
455/65	22.5	88 oz.	11
495/45	22.5	80 oz.	10
11.00	24	48 oz.	6
12.00	24	48 oz.	6
11	24.5	48 oz.	6
285/75	24.5	48 oz.	6

This product is not intended for use in passenger or light truck highway applications. This product may be applied to highway vehicles rated at 18,000 lbs. (8,182 kg) gross vehicle weight and above.



EcoSeal is the safe, responsible sealant for your tires and wheels.

- Permanently seals 1/4" injuries in the tread area
- Does not corrode wheels even after long exposures to high temperatures
- Uses recycled rubber and 100% biodegradable ingredients; completely glycol free

Tips for using the hand pump:

- Use slow steady up/down hand pump strokes to avoid clogging.
- Each up/down stroke of the 5-gallon hand pump delivers 8 ounces of sealant.
- One 5-gallon pail contains 640 ounces.

To install from a pail with the hand pump:

- * Use slow steady up/down hand pump strokes to avoid clogging.
 - ** Each up/down stroke delivers 8 ounces of sealant.
1. If there is a known injury, rotate tire so that the injury is at the 6:00 position.
 2. Remove valve core from stem. Deflate tire. Note: Hand pump may be used against tire pressures up to 30 psi.
 3. Connect hose assembly to the valve stem.
 4. Read recommended tire seal quantity – each pump stroke delivers 8 ounces.
 5. Pull up on pump handle until fully extended.
 6. Slowly push down on pump handle until it rests solidly on pump base. Repeat as required for proper quantity.
 7. Remove hose assembly from the valve stem.
 8. Insert valve core and inflate tire to recommended air pressure.

Occasionally, the ball check at the bottom of the down tube may become stuck. Simply remove pump from sealant, remove ball check housing and clean.



An optional transfer pump (above) can be used to move sealant from 55-gallon drums to 5-gallon pails. The hand pump (below) fits on 5-gallon pails.



International Marketing, Inc.

25 Penncraft Avenue, Suite C • P.O. Box 2002 • Chambersburg, PA 17201
Toll Free 800-233-7086 • Telephone 717-264-5819 • Fax 717-264-5483